

Diversey™

suma®

Café AutoTab 3,6g x 20mm

C1.5

Espresso machine cleaning tablets

Description

Coffee machine cleaning tablet for daily cleaning of a broad range of traditional and fully automatic espresso machines. Formulated for powerful cleaning and easy rinsing and can be used for cleaning of traditional espresso machines, fully automatic machines, and soaking coffee and espresso machine parts.

Benefits

- Formulated for controlled solubility, powerful cleaning and easy rinsing
- Sized and designed for the delivery chambers of a broad range of fully automatic espresso machines and other coffee equipment.
- Ingredients are phosphate free, odorless and biodegradable, every jar is fully recyclable

Use instructions

Fully automatic espresso machine:

1. Intended for daily use.
2. Insert one Suma Café AutoTab C1.5 cleaning tablet in machine opening and follow manufacturer's "Maintenance and Cleaning" instructions.

Traditional espresso machines / Back flush (each group head):

1. Insert blind filter and add 1 tablet per group. Replace portafilter in group.
2. Activate brew cycle for 10 seconds. Stop 10 seconds. Repeat 5 times.
3. Remove portafilter, rinse blind, reinsert. Repeat step (2) without Suma Café AutoTab C1.5 tablet to rinse.
4. Make and discard a shot of espresso to ensure no residue remains.

Traditional espresso machines / Portafilter soak:

1. Soak filters and metal of portafilter for 30 min in 2 tablets per liter of hot water.
2. Rinse with potable water.

Traditional Espresso Machine / Coffee brewers:

1. Empty coffee from equipment and add 4 Suma Café AutoTab C1.5 tablets per 2 liters of brewer capacity directly into brew basket.
2. Run a full brew cycle into vessel. Hold for 30 minutes.
3. Rinse with clean hot water.



**This dosage is according to optimal conditions, recommendations may vary, please consult with your Diversey representative for directions.*



DiverseyTM



suma[®]

Café AutoTab 3,6g x 20mm

C1.5

Technical data

Appearance: solid white tablet

pH value (10g/l): 10,0-10,3

The above data is typical of normal production and should not be taken as a specification.

Safe handling and storage information

Full guidance on the handling and disposal of this product is provided in a separate Safety Data Sheet; sds.diversey.com.

Store in original closed containers away from extremes of temperature.

Only for professional users / specialists.

Product compatibility

Under recommended conditions of use, Suma Café AutoTab C1.5 is suitable for use on stainless steel materials commonly encountered in the kitchen. Do not use on aluminium.

Approvals

This product carries Kosher, Halal and NSF certifications.